

## **ASSEMBLY INSTRUCTIONS**

ITEM NO: I256-451 1 Drawer NS

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.




TOOLS REQUIRED (NOT PROVIDED)
PHILLIPS SCREWDRIVER

HARDWARE LIST:				
No.	Description	Sketch	Quantity	
Α	Bolt Ø5/16" x 1-1/2"	9	4 PCS	
В	Lock Washer Ø5/16"		4 PCS	
С	Flat Washer Ø5/16" x 7/8"	0	4 PCS	
D	Allen Wrench 4mm		1 PC	

COMPONENTS LIST:				
No.	Description	Sketch	Quantity	
1	Case		1 PC	
2	Metal Leg		4 PCS	

## **FUNCTIONALITY INSTRUCTION**



BEFORE USING THIS PRODUCT PLEASE READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS. Save these instructions for future reference.


FOR INDOOR USE ONLY

## **ASSEMBLY INSTRUCTIONS**

ITEM NO: I256-451 1 Drawer NS

STEP 1: Put the case upside down on a soft surface.

STEP 2: Each metal leg will come with screw pre-installed with a 1/4" lag as shown below. Adjust as needed to ensure the 1/4" lag. Insert the screw on each metal leg into the buckle plate on the case and push it down to the suitable position. Attach the metal legs by using 4 bolts (A), lock washers (B) and flat washers (C). Use the allen wrench (D) to tighten the four bolts. If the leg is loose in the buckle plate, the leg should be removed and the screw adjusted as needed. Once legs are all secure, return the case to the upright position.



<u>STEP 3:</u> Taking out the knob by removing the screw when opening the drawer, attach the knob to the front of the drawer by screw as shown below.

