

ASSEMBLY INSTRUCTIONS


ITEM NO: I224-307 66" Desk for Return

I224-308 48" Return Desk

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.



UNIT SHOULD BE INSTALLED BY 2 OR MORE PERSONS.



TOOLS REQUIRED (NOT PROVIDED)
PHILLIPS SCREWDRIVER

HARDWARE LIST: I224-307			
No.	Description	Sketch	Quantity
A	Bolt Ø1/4" x 1-9/16"	(1)	6 PCS
В	Lock Washer Ø1/4"	0	6 PCS
C	Flat Washer Ø1/4" x 3/4"	0	6 PCS
D	Allen Wrench 4mm		1 PC

BEFORE USING THIS PRODUCT PLEASE READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS. Save these instructions for future reference.

FOR INDOOR USE ONLY



ASSEMBLY INSTRUCTIONS


Distributed by Furniture Values International, LLC ITEM NO: I224-307 66" Desk for Return I224-308 48" Return Desk FUNCTIONALITY INSTRUCTION Flip down keyboard tray Felt-lined top drawer Keys for file lock. Do not trash. Locking file drawer hold letter or legal size files Remove Remove the wood screws Leveler on Legs on the side of drawer box Adjust the leveler to remove the rod loops when necessary and file rods if necessary. 2 AC outlet Power Pack on the outside of the Pedestal Flip down keyboard tray Adjustable wood shelf If you prefer to adjust the shelf location, remove the screws and Levéler on Legs move shelf brackets to the Remove Adjust the leveler desired location. Then secure the when necessary brackets to shelf with screws. Metal plate Press here to release Hook latch

ASSEMBLY INSTRUCTIONS

ITEM NO: I224-307 66" Desk for Return

I224-308 48" Return Desk

If the desk is too wide to go through the door, you need to remove the legs. As shown below, use an Allen Wrench (D) to remove the bolts from the legs of the desk.



STEP 1:Align the holes in the desk end connector with the holes in the return. Use 6 bolts (A), lock washers (B) flat washers (C) to connect desk and return. Use an Allen wrench tighten all the bolts.

